

3 Steps to convert the Kite from two lines into four lines.

Step 1.) open pig tail on both sides and detach it from the back bridle line and the front bridle line (1).

Step 2.) detach the back bridle line on both sides from the pig tail on the kite (2)

Step 3.) slide the front line bridle through the pulley (3)

